

STANDARD

TRUCK AND TANK LLC | WE SET THE STANDARD

PREVENTIVE MAINTENANCE & INSPECTION

General schedule. Component-specific instructions supplied with the unit control.

DAILY SAFETY RULES

- Never work beneath an unsupported body. Empty the body and engage every supplied body prop.
- Never rely on hydraulic pressure to support a raised body.
- Correct unsafe conditions before operating the truck.
- Follow the chassis, hoist, PTO, tarp, and accessory manufacturer's instructions.

INSPECTION AND SERVICE SCHEDULE

Interval	Inspection / maintenance
Before each use	Body, hoist, hinges, tailgate latches, tarp, hydraulic hoses and fittings, controls, props, mounting hardware, leaks, warning labels
Weekly	Grease fittings, pivot points, cylinder pins, rear hinges, tailgate hinges; inspect hose routing, wiring, connectors, and fasteners.
Monthly	Check hydraulic fluid condition, mounting alignment, welds, body guides, tarp hardware, lighting, controls, and safety-prop condition
Every 90 days	Document fastener inspection/retorque, hydraulic-system inspection, electrical inspection, hinge wear, coating damage, and fuel
As conditions require	Clean corrosive or trapped material, repair coating damage, adjust mechanisms, and increase service frequency for severe du

SERVICE RECORD

Date	Mileage / hours	Work performed	Technician

Date	Mileage / hours	Work performed	Technician